

Quick Start Guide

Real-Time 960H Recording VMAX 960H CORE



Please note	Please note that the Accessory Kit and Shipping Box contain the following items :							
Items	Photo	Quantity	Items	Photo	Quantity			
CD (DVR&Software) & Quick Start Guide		l Set	I2V DC Adaptor रु Power Cable	₽ \$	lS∈t			
IR Remote Control		l Set	Rubber Mount & Screws	••••	l Set (4 Pieces) 4 Pieces (Top cover)			
			USB Mouse	Ø	ISet			

Default Login Information (ID: Admin / No Password)

ATTENTION PLEASE !!!

This document is intended to serve as a quick reference page for initial set-up. It is recommended that the user read the entire instruction manual before beginning.

Engineered in U.S.A and Korea Manufactured in Korea

REAR PANEL

W 4CH Back Panel



W 8CH Back Panel





No.	I/0	Description				
1	Video Input	Camera Inputs (Supports NTSC/PAL)				
2	Audio Input	Audio Input (with Amplifier)				
З	Audio Output	Audio Output (with Amplifier)				
4	Video Output	Main Composite Monitor Output				
5	Spot Output	Spot Composite Monitor Output				
6	USB Port	USB 2.0 Port for Mouse Operation, Backup Device, or Firmware Update				
7	HD OUTPUT	HD Output				
8	LAN Port	4ch : I/I0/I00M 8ch/I6ch : I/I0/I00/I000M				
9	Power Input	4ch : I2 VDC at 2Amps 8ch/I6ch : I2 VDC at 3Amps				
ю	Sensor Input	Sensor Input				
11	Alarm Output	Alarm Output				
15	RS-485 Port	PTZ Camera or External Keyboard Controller Connection				

INSTALLATION

W 4/8/16 Channel DVR Compact Case



INO.	Buttons	Functions
I	LED Indicator	Indicates the system's status. From left to right: Power, Recording, Network Connection
2	USB Port	USB Port (Ver. 2.0) for Mouse Operation, Backup D Firmware Update

W Initial Setup

- I. Mount and install all necessary cameras and external devices. Refer to their individual manuals for additional information.
- 2. Place the DVR in its final position. See the Installation Safety Tips below for additional information.
- 3. When all necessary cameras and monitors are setup in their permanent location, connect them to the DVR using the proper cabling. Use this QSG and refer to the full manual for additional information.
- 4. When all connections have been made, connect the DVR to an appropriate power supply. The DVR will booth up automatically.
- 5. When the DVR boots up, it will be in protective mode, and will not allow access to the different menus until a user enters a proper password. To unlock the DVR, right-click anywhere on the screen. The login pop-up window will appear. Enter your username and password. The DVR's default username and password are: admin/ no password.
- 6. When the DVR boots up for the first time, you will be guided through the Quick Startup Wizard. See the next page for more information.



W DVR Installation Safety Tips

- I. Make sure the cameras and the monitors are properly connected to the DVR.
- 2. The DVR should be placed in a dust and moisture free environment. It must never be exposed to direct sunlight. Server room temperature is highly recommended to reduce the chance of overheating. Overheating may cause the DVR to become unstable.
- 3. During the boot process, the DVR should not be interrupted by pressing any buttons on the mouse, or remote controller. Do not unplug the power adapter or turn the DVR off during the boot process.
- 4. A UPS (Uninterruptable Power Supply) is highly recommended to prevent of the DVR during a power outage.



INITIAL SETUP

W Quick Startup Wizard

The Quick Startup Wizard is designed to make the installation process of your new DVR as quick and easy as possible. This startup wizard will automatically appear when you first boot up your DVR. It will guide you through setting up some of the DVR's more critical features required for its proper function.

The Quick Startup Wizard will take you through setting up Date & Time, Recording Setup, Network Setup and Quick Setup.

If you do not want to follow the Startup Wizard uou can disable it bu clicking the [CANCEL] button and adjusting your settings manually via the DVR's main menu.

Quick Startup Wizard	Network	
NetworkType	Static IP IP. Detect)
IP Detect Progress	0	1
IP Address	192.168.1.160	
Subnet Mask	255.255.255.0	
Gateway	192.168.1.1	
DNS Server 1	0.0.0.0	
DNS Server 2	0.0.0.0	
TCP/IP/Mobile Port	9010	
Web Port	80 8	
Bandwidth Limit	100 Mbps	
	Use UPNP	
	Auto Private IP Setup (NAT Traversal)	
Default	Previous Next Cance	-

🚾 Main Menu

The Main Menu (Setup Menu) system includes six (6) sub-menus: System, Device, Record, Network, Backup, & Q. Setup, To access the Setup Menu. right-click anywhere on the screen and select 'Setup Menu'.

The DVR's default user ID and password are: admin/ no password.

W Navigation

Use the supplied USB mouse for easy operation. Alternatively, use the following remote controller key pad.

- Use the (Enter) button to select or enter edit mode for a highlighted selection.
- Use the directional keys \oplus to move through a menu or list.
- Use the [Menu] button to enter or exit a menu or setup window.

W Date and Time Setup

- I. Go to the System Menu and select SYSTEM INFO. Click on the pencil icon next to the Date/ Time to enter edit mode.
- 2. Select the proper display format from the [DATE/TIME FORMAT] drop down lists.
- 3. Select the appropriate date and local time in the (DATE/ TIME) sectio
- 4. Select the appropriate time zone from the [TIME ZONE] drop down list.
- 5. If applicable, enable Daylight Savings mode.

W Formatting the Hard Drive Disk

After adjusting the time and date for the first time, it is highly recommended to format your Hard Disk Drive.

Digital Video Recorder VMAX960H CORE

- I. Go to the System Menu and select the HDD submenu.
- 2. Select the Check box next to the HDDs.
- 3. Click the (HDD Clear) button.
- 4. When the HDD formatting is complete, exit the main menu to save all changes.





RECORD SETUP

W Recording Configuration

- I. Go to the Main Menu and select RECORD.
- 2. In the record window, select the Record Setup submenu.
- 3. Choose the desired resolution, frame rate, quality and recording type for continuous recording. (Continuous)
- 4. Choose the desired frame rate, guality and recording type for Event recording. (Event)
- 5. Individually configure the settings for each channel, or use the [COPY SETTINGS] button to applu changes to multiple cameras.
- 6. To setup a specific recording schedule, go to the SCHEDULE submenu. You can setup the record schedule by applying different recording modes at different daus and times.
- a. Select a record mode from the options on the top of the screen.
- b. Using your mouse, click, hold, and drag to select multiple days & hours.
- c. You can setup a unique recording schedule for each channel or applu the same recording settings to all channels.
- d. You can setup special days as "holidays" either by their date (December 24th) or by their time of the month (Third Thursday of November).

) (Q	20 🔾	ی 🌍		RECOR	D			
Rec	ord Setup	Panic Rece	ord Schedule	Holid	ay			
Gb	Resolution		Normal		Event	Pre-	Po	st
		FPS	Quality	FPS	Quality	Alarm	Ala	rm
1	960*480 -	1 💌	Highest 💌	15 💌	Highest 💌	5 -	5	
2	960*480 -	15 💌	Highest 💌	15 💌	Highest 💌	5 -	5	
3	960*480	15 💌	Highest 💌	15 💌	Highest 💌	5 -	5	
4	960*480	15 💌	Highest 💌	15 💌	Highest 💌	5 -	5	
	opy Setting							
D	Mault	Help			Save		Cano	:el

W Quick Setup

The Quick Setup Menu offers an automatic recording and HDD calculator. By entering your anticipated recording days, or the desired recording resolution, the DVR will provide you with the estimated days recorded on your current HDD space.

To setup recording based on recording day:

Select how many days you wish to record on your current storage. The system will populate recommended recording resolution, frame-rate, and quality.

To setup recording based on recording resolution:

Select the desired recording specifications. The system will display the number of days that will be recorded on your available storage



Note: To manually setup recording configurations, Quick Setup must be DISABLED. If the "Use Quick Setup" option is enabled, the system will ignore all other configurations set manually.

Digital Video Recorder **MAX 960H CORE**

NETWORK SETUP

W Network Setup

The Network setup menu allows you to configure the DVR's network settings to allow remote connection from within the same network or externally via the Internet. To setup the DVR's network settings, right click anywhere on the screen and go to Setup Menu > Network.

Note: The following information are general guidelines. These may vary by network and router specifications. Contact your installer or ISP for additional information

		Dealer Page
NetworkType	Static IP	IP Detect
IP Detect Progress	• •	
IP Address	192.168.1.160	æ
Subnet Mask	255.255.255.0	æ
Gateway	192.168.1.1	Ð
DNS Server 1	0.0.0.0	æ
DNS Server 2	0.0.0.0	Ø
TCP/IP/Mobile Por	9010	æ
Web Por	80	B
Bandwidth Limi	100 Mbps	
	Use UPNP	
	Auto Private IP Setup	(NAT Traversal)

- I. In the [Network] menu set "Network Tupe" to [Dunamic IP] and click [IP DETECT]. This allows the DVR to scan your network and automatically configure its settings to match your network's requirement. This is recommended to simplify and make sure your DVR's settings are according to the network's requirements
- 2. Once the system generates all the information based on your network requirements, you can change the Network Type to Static and save all the changes. A static IP address will not be changed by the network.
- 3. In order to view your DVR remotely from withing the network or via the Internet. you need to make sure the ports associated with the DVR are opened in your router. Some internet service providers block port 80. It is recommended to change the web port number to 8I or 82.
- 4. Access your router by entering its external IP address in your web browser (this information can be found by running an ipconfig command on your computer's Command Prompt. The router's external IP address is the GATEWAY address.) This step is only necessary if you are planning to connect to your DVR from a different network, over the internet.
- 5. Check the settings in your router and setup the DVR for external connections by performing port forwarding. Contact your Network Administrator and review the manual for more information. Visit www.portforward.com For additional information on how to setup port forwarding in your specific router model.
- 6. Once the router settings have been configured correctly, open an internet explorer page and enter your router's external IP address:DVR's port number (Example: 72.243.193.215:81). See "Web Viewer" in this QSG for more information.

W Reaisterina DDNS

The DDNS address provides your DVR a URL address, easier to remember than an IP address. This is a free feature supported by Digital Watchdog for its customers I. Go to the Network setup menu, and select the 'DDNS' tab.

- 2. Check USE DDNS to enable.
- (Make sure the DVR's web port has been properly setup in your router). 3. Select DWDDN2.net (default).
- 4. Enter a name for your DVR and click the CHECK button. If the name is available, the system will display the following message "THIS DVR NAME CAN BE USED". Click SAVE to save all changes.
- 5. To use your DDNS, open an Internet Explorer page and enter the DDNS in the address bar: DVRname.dwddns2.net.pot-number. (example: http://vmax960core.dwddns2.net.80)

NUMBER OF STREET	and an and a state of a state	Real and Real	
Network DDNs Noti	Health Check	Dealer Page	
	Use DDNS		
DDNS Server	dwddns2.net	_	
Web Port	80		
DVR Name		P	
User		Ð	
Password		P	
Check	Start		

SPECIAL FUNCTIONS

🞹 Health Check

- The VMAX960H CORE™ offers a uniquely true DVR health monitoring, with pop-up messages and e-mail notification on video loss, recording failure, and storage failure. To setup:
- I. Go to Setup Menu > Network > Health Check.
- Check the box next to "Enable Health Check"
- 3. Check the box next to the conditions you would like to be notified on. 4. Set the occurrence intervals.
- (For Example: when video loss occurs more than I time a minute)
- 5. Select whether to receive a pop-up message when conditions are met.
- 6. Go to the Notifications tab in the network setup page. 7. Under e-mail notifications, make sure the Health Check option is enabled and
- your e-mail address is set to receive notifications from the DVR. See the full manual for additional information on e-mail notifications setup. When any of the failures occur beyond the set conditions, the system will display a pop-up alert and send an e-mail notification.

Interval		Count	Warning Condition
🔿 Day	1	VideoLoss	0 🚔
O Hour	1 🚖	Recording Failure	•
O Min	10	HDD Failure	
Pop up Message			

🚾 Firmware Upgrade

The VMAX960H CORE™ allows for remote and USB firmware upgrade.

To upgrade the DVR using a USB drive:

- I. Connect a USB drive with the new firmware to the DVR's USB port. 2. Right-Click anywhere on the screen and select Setup Menu > System > System Info.
- 3. Press the 'Upgrade' button next to the version number.
- 4. Select USB from the method drop-down menu.
- 5. Press 'Scan' to find the USB device and proper firmware file. The system will display all supported files on the USB in drop down. Make sure you select the proper upgrade file.
- 6. The new firmware version will appear under the current version.
- 7. Press 'Start' to begin upgrade. Do not disconnect the power from the DVR or the USB until the upgrade is completed.

To upgrade the DVR using the FTP Server:

- I. Right-Click anywhere on the screen and select Setup Menu > System > System Info.
- 2. Press the 'Upgrade' button next to the version number.
- 3. Select FTP from the method drop-down menu. The FTP's login information will automaticallu be filled out.
- 4. If a new firmware is available, the new firmware version will appear under the current version.
- 5. Press 'Start' to begin upgrade. Do not disconnect the power from the DVR or the USB until the upgrade is completed.



REMOTE CLIENT

W Prot CMS (Central Monitoring Software)

The Pivot CMS is included with the DVR. Install it on your computer from the accessory CD. After installation. double-click on the Pivot shortcut to launch the software. (Pivot's user/ Password: Administrator/ no password)

(internet in the second s	Registration	×
Non Cont Select Image: Selection Selection Selection	Name	
	IP Address or Port 9010 Web port 80 ID Password	Search
	Channel Model DVR / NVI	EX) 1-4, 1-8, 1-16
	Aspect Ratio Custom	Cancel

To Add a site:

- I. Right-click on the device list panel and select "Add Site"
- 2. Make sure VMAX960H CORE™ is selected from the Model drop-down list.
- 3. Enter your DVR's information:
- a. Name
- b. IP Address. If you are trying to connect to the DVR from a PC that is in the same network as your DVR, click "Search" to auto-discover your DVR.
- c. Port will be filled out to Default(80).
- d. ID and Password- to access the DVR.
- e. Channel- enter the span of channels available on your model (ex. I-4).
- 4. Press 'OK' to save, or 'Cancel' to delete all changes.
- 5. To connect to the newly added site, click and hold on the name and drag it into the viewing area. Select to view Live/ Playback.

W Web

The VMAX960H CORE™ is accessible from a user-friendlu web client.

If you are connecting to the DVR using Google Chrome, download the IE Tab extension. If you are connecting to the DVR using IE 9 or newer, you can access the DVR's web client using the compatibility mode.

- I. Open an Internet Explorer web page.
- 2. Enter the DVR's IP address or DDNS URL and press enter.
- 3. Enter the User ID and Password for the DVR and click Enter.



(Default User/ Password: admin/ no password). The DVR's web viewer will be displayed.

Note: If you are using IE, install all Active-X Control notifications to view video from the DVR

W Held

Help The "HELP" button will help you understand how to setup several important settings such as DDNS. NOTIFICATION. BACKUP. SCHEDULE, NETWORK, and CAMERA For example, if you need help about how to set "BACKUP", Click "HELP" button at the right bottom of the BACKUP menu.

🛊 🕒 🚾 🕥 🚱 💞 🗲	QUICK SET	TUP	
Help			
Quick Setup			
* Use Quick Setup			
- Check the "Use Q	uick Setup" box to Ena	ble	
* (this will overwrite a	all other record setting	s of the system)	
* Input Desired Day			
- Select the number	of days to record		
* Record Resolution			
- Select the recordin	ng resolution for all cha	annels	
Recording FPS			
- Select the Frames	Per Second for all char	nnels	
	4 1/3 🕨		ок
Default Help		Save	Cancel