



INSTALLATION GUIDELINES and GENERAL INFORMATION:

1. See the specific system wiring diagram for the balance of the wiring connections required.
2. All low voltage wiring is #18 AWG, unless otherwise noted.
3. Observe all local and national electrical codes.
4. Each system is wired independently and uses an independent 24VAC (model SS106) transformer (or equivalent).
5. Wiring shown is also applicable to our model EK117 and/or EK117B Emergency-Call kits.
6. Wire colors shown are the pigtail wires on the back of the push or pull station(s).



42 Central Drive, Farmingdale NY 11735-1202
(631) 777-5500 Fax: (631) 777-5599
TOLL-FREE Technical Line 1-800-666-4800
Email: info@alphacommunications.com

TYPICAL WIRING INSTRUCTIONS FOR SF117/2x OR SF154A PULLCORDS

With CDL101LED, CDL123B, LI381 or
LI123B Corridor Light units and separate
SS106 transformers for each light unit.