

VZ-CME SERIES

19.5", 21.5" and 24" ECONOMIC

LED CCTV MONITOR **USER MANUAL**



ViewZ[®]
www.viewzusa.com

Please read this manual thoroughly before use, and keep it handy for future reference.

CONTENTS

Safety Instruction	3
1. Mark Indication & Substance	4
2. Warning	4
3. Caution	5
4. Operational Temperature & Humidity	5
5. Dot Defect (dead pixel) of TFT	5
6. FCC RF INTERFERENCE STATEMENT	6
Installation	7
1. Package	7
2. Interface	8
3. Remote Control Function	9
Function	10
1. Monitor Button Function	10
2. OSD Control and Function	11
Mounting Guide	16
Specification	17
Trouble Shooting	18
RMA	19
Warranty	20

SAFETY INSTRUCTION

Important Safety Instruction

1. Read all warnings.
2. Follow all instructions to ensure longevity of monitor.
3. Do not place the monitor near water.
4. Clean only with dry cloth.
5. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
6. Do not install near any heat sources such as radiators, heat registers, stoves, or other heat generating devices.
7. Do not override the safety purpose of the polarized or grounding-type plug.
8. A polarized plug has two blades with one wider than the other.
9. A grounding type plug has two blades and a third grounding prong.
10. The wide blade or the third prong are provided for your safety.
11. If the provided plug does not fit into your outlet, consult with electrician for replacement of the outlet.
12. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and the point where it connects to the monitor.
13. Only use attachment/accessories specified by the manufacturer.
14. Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the monitor. When a cart is used, use caution when moving the cart & monitor in combination to avoid
15. injuries.
16. Unplug the monitor during lightning storms or when unused for long periods of time.
17. Refer all servicing to qualified service personnel. Servicing is required when the monitor has been damaged in any way.



The monitor shall not be exposed to dripping or splashing and objects containing liquids, such as vases shall be placed near the monitor.

The monitor should have ample distance (e.g. 10cm) from the wall for sufficient ventilation.

SAFETY INSTRUCTION

Important Safety Instruction

Mark Indication and Substance



CAUTION : TO REDUCE THE RISK OF ELECTRICAL SHOCK,
DO NOT REMOVE COVER (OR BACK). NO USER
SERVICEABLE PARTS INSIDE. REFER SERVICING TO
QUALIFIED SERVICE PERSONNEL



This symbol is intended to alert the user to the presence of uninsulated & dangerous voltage within the monitor's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the monitor.

Warning

- Do not use damaged or loose cables and plug.
- Do not pull the plug out by the wire nor touch the plug with wet hands.
- Use only a properly grounded plug and receptacle.
- Do not connect too many extension cords or plugs to one outlet.
- Do not excessively bend the plug and wire.
- Do not disconnect the power cord while it's still plugged into the monitor.
- Do not place any heavy objects on the power cord. Damage to the cord may cause shock or fire.
- Never open the monitor. There are no user-serviceable parts inside and opening will void warranty.
- Removing covers may expose you to dangerous shock hazards or other risks.
- Keep any heating devices away from the power cable and monitor.
- Do not place the monitor near water.
- Do not insert objects of any kind into the monitor's open slots, as they may touch dangerous voltage points.
- Please follow the laws and regulations of your municipality to dispose of the tube properly.
- Do not use the monitor in high temperature, humid, dusty or oily areas.
- Do not install the monitor where it will be exposed to continual vibration.
- Keep the plastic packaging out of children's reach.
- If any damage is defected upon first opening the box, contact agency from which you bought the monitor directly.
- If your monitor does not operate normally – in particular, if there is any unusual sound or smell coming from the monitor – unplug it immediately and contact an authorized dealer or the service center.

SAFETY INSTRUCTION

Important Safety Instruction

Caution

- If the connector between the plug and the pin is dusty or dirty, clean it properly using a dry cloth.
- Make sure to unplug the power cord before cleaning the monitor.
- Make sure to leave a gap between monitor and wall.
- Do not drop the monitor when moving it.
- Place your monitor in a location with low humidity and a minimum dust.
- Install the monitor base on a showcase or shelf so that the end of the base does not protrude from the showcase or shelf.
- Do not place the monitor on an unstable or small surface area.
- Do not install inside a vehicle.
- Disconnect the plug from the outlet during storms or lightning or if it has not been used for a long time.
- Do not try to move the monitor by pulling on the power cord.
- Do not cover the vents on the monitor.
- When moving the monitor, turn off and unplug the power cord. Make sure that all cables, including HDMI cable and cables connected to other devices, are disconnected before moving it.
- Place the monitor out of children's reach, as they could damage it by hanging onto it.

Available Temperature & Humidity

- Operating Temperature : 14°F ~ 122°F / -10°C ~ 50°C
- Operating Humidity : 20 ~ 70% RH

Dot Defect (dead pixel) of TFT

ViewZ monitors are manufactured using high-end semiconductor technology with precision ratings of 99.9% and above. However, it may be the case that certain RGB and white pixels seem darker (or entirely unlit i.e. black).

Modern production methods cannot guarantee an absolute fault-free monitor. To this effect, no LED manufacturer can guarantee a defect free panel. A few isolated pixel or sub-pixel faults are considered tolerable and different policies exist that govern the amount of these tolerable values.

While most pixel faults occur in isolated regions, a cluster of dead pixels or sub-pixels can sometimes form for which a separate ruling applies. A cluster is defined as an area of 5x5 pixels. ViewZ's policy on pixel failure: either as an isolated fault or in the form of a cluster is outlined on the website: www.viewzusa.com

FCC RF INTERFERENCE STATEMENT

Note

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio, TV technician for help.
- Only shielded interface cable should be used.

Finally, any changes or modifications to the equipment by the user not expressly approved by the grantee or manufacturer could void the users authority to operate such equipment.


► DOC COMPLIANCE NOTICE

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the radio interference regulation of Canadian Department of communications.

INSTALLATION


Installation Tools

The following tools may be required depending on your installation.



Assembly Components - provided

Your ViewZ monitor is shipped with all proper installation hardware and components. If there are parts missing and/or damaged, please stop the installation and contact ViewZ USA at (888)-998-4399.



Mounting Option

Your ViewZ monitor is compatible with ViewZ monitor mounts. For more information, please contact ViewZ USA at (888)-998-4399.

Wall Mount

- Part # WM05 VESA 50, 75, 100
15mm Low profile



- Part # WM11 Tilting -70° ~ +70°
Swivel 180°




- Part # AM01 Tilting -70° ~ +70°
Swivel 180°



CONNECT EXTERNAL EQUIPMENTS

Interface Input Ports

The following image is the description of interface input ports of BNC Monitor




1. DC 12V IN
2. HDMI IN
3. DVI INC
4. VGA IN
5. Audio IN / OUT

REMOTE FUNCTION

Remote Controller Function

1. Power
2. Auto: Auto Adjustment for Input Source
3. Up
4. Right
5. Menu: Enter OSD Menu
6. Left
7. Down
8. Mute: Sound Mute On/Off
9. Exit: OSD Selection Cancel & Back / Close OSD Menu
10. 4:3/16:9: Adjust Aspect Ratio
11. HDMI Input Select
12. DVI Input Select
13. VGA Input Select




Display image, sound and custom settings can be adjusted in OSD (On Screen Display) menu by Remote Controller.
To adjust monitor setting value :

1. Press the **'MENU'** button to enter the OSD menu
2. Press the **▲ / ▼** buttons to select the desired sub-menu. The selected sub-menu will be highlighted
3. Press the **'MENU'** button to enter the sub-menu to adjust different items
4. Change the value you wish to adjust by using the **◀ / ▶** buttons
5. Press the **'MENU'** button to confirm the adjustment on sub-menu
6. Press the **'EXIT'** button to exit the sub-menu to go back to the previous menu
7. Press the **'AUTO'** button to adjust monitor setup automatically. It only works for VGA input
8. Without entering OSD MENU, press **◀ / ▶** buttons to adjust the audio volume
9. Without entering OSD MENU, press **HDMI, DVI & VGA buttons** to select desired input source
10. Press **'4:3 / 16:9'** button to change aspect ratio or zoom
VGA input source only allows monitor to change the screen to 4:3 and 16:9 aspect ratio
HDMI & DVI input sources allow monitor to change the screen to 4:3 and 16:9 aspect ratio, or make the zoom for monitor
11. Press the **'MUTE'** button to mute audio

CONTROL AND FUNCTION

On Monitor, Button Control



- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Source
Select an input source 2. Menu
Enter or exit the OSD / Select a menu on OSD 3. Left & Right ◀ (VOL) ▶
Change the value on selected menu 4. Up & Down ▲ ▼
Switch a menu on OSD | <ol style="list-style-type: none"> 5. Power
Monitor power on / off 6. LED Indicator
Green color: monitor on
Red color : monitor off
Red (Blinking) color : power saving mode |
|--|--|

Monitor Button Function


Display image, sound and custom settings can be adjusted by monitor buttons - located at the rear side - right-bottom-corner. To adjust monitor setting value :

Press the **'MENU'** button to enter the OSD menu

1. Press the **'SOURCE'** button to select input source
2. Press the ▲ / ▼ buttons to select the desired sub-menu. The selected sub-menu will be highlighted
3. Press the **'MENU'** button to enter the sub-menu to adjust different items
4. Change the value you wish to adjust by using the ◀ / ▶ buttons
5. Press the **'MENU'** button to confirm the adjustment on sub-menu
6. Press the **'EXIT'** button to exit the sub-menu and go back to the previous menu

CONTROL AND FUNCTION

Select Input Source - Monitor Button Function




Press 'Source' button on monitor

Press ▲ ▼ buttons to change input source



If you push 'SOURCE' button on monitor, you will see all available input sources. If the input source is connected, you will see it as the selected input source.

Volume



Press ◀ / ▶ buttons of monitor & remote controller to adjust volume

Auto Detect Source / No Signal / Out of Range Message



No Signal Message : If you did not connect any input source, monitor will show 'No Signal' message and go into stand-by mode.

Input Message : If you connect any input source, monitor will detect it automatically and identify it by the type of input source it is - HDMI, DVI or VGA.

Out of Range Message: If you connect a specific input source that is out of range on panel frequency (ref. page #17), you will see this message. In this case, please connect proper frequency input source.

CONTROL AND FUNCTION

Picture




▲/▼ MOVE ◀/▶ SELECT(ADJUST) MENU RETURN

FUNCTION		VALUE
BRIGHTNESS	Adjust the Brightness of screen	0 ~ 100
CONTRAST	Adjust the Intensity(Gain) of screen	0 ~ 100
GAMMA	Adjust the Strength of RGB color	ON / OFF

Position



▲/▼ MOVE ◀/▶ SELECT(ADJUST) MENU RETURN




Auto Adjustment Process

FUNCTION		VALUE
PHASE ¹⁾	Adjust the number of horizontal picture elements	0 ~ 100
CLOCK ¹⁾	Stretch In/Out horizontal image of display	0 ~ 100
H-Position ¹⁾	Adjust the horizontal picture position	0 ~ 100
V-Position ¹⁾	Adjust the vertical picture position	0 ~ 100
Auto Adjustment	Automatically adjust the picture position	

1) Only available in VGA mode

CONTROL AND FUNCTION

Color



▲/▼ MOVE ◀/▶ SELECT(ADJUST) MENU RETURN

FUNCTION		VALUE
COLOR TEMPERATURE	Adjust the color setting of screen	See table below
RED ¹⁾	Adjust the intensity of RED color	0 ~ 100
GREEN ¹⁾	Adjust the intensity of GREEN color	0 ~ 100
BLUE ¹⁾	Adjust the intensity of BLUE color	0 ~ 100

1) Only available when select 'USER' mode on 'COLOR TEMPERATURE'

AVAILABLE COLOR TEMP.

5000K

6500K

7500K

8200K

9300K

11500K

sRGB

USER

CONTROL AND FUNCTION

OSD



▲/▼ MOVE ◀/▶ SELECT(ADJUST) MENU RETURN

FUNCTION		VALUE
H-Position	Adjust the horizontal OSD position (default : 50 / middle)	0 ~ 100
V-Position	Adjust the vertical OSD position (default : 50 / middle)	0 ~ 100
Transparency	Change transparency background of OSD menus (default : 0)	0 ~ 4 ¹⁾
OSD Time Out	Set the OSD display time (second) (default : 5)	0 ~ 60

1) 0 : No transparency of OSD Menu

4 : Max Transparency of OSD Menu

CONTROL AND FUNCTION

Setup



▲/▼ MOVE ◀/▶ SELECT(ADJUST) MENU RETURN

	FUNCTION	VALUE
LANGUAGE	Set the language of the OSD menu	English, Spanish, French Italian, Deutsch, Dansk, Polski
MUTE	Set the audio volume mute	ON / OFF
INPUT	Change the input source	HDMI / DVI / VGA
DCR	Set the automatic adjustment for overall brightness	ON / OFF
DISPLAY SIZE	Change the display ratio	16:9 / 4:3 / ZOOM ¹⁾
RESET	Reset the monitor settings to the factory default	


1) HDMI / DVI supports 16:9 / 4:3 / ZOOM

VGA only supports 16:9 / 4:3

MOUNTING GUIDE

Wall Mounting (Optional)

VZ-CMP monitors are suitable for VESA wall mount (not included in the delivery).



1. VZ-19CME, VZ-22CME, VZ-24CME : VESA WALL MOUNT 75mm x 75m



Attention!

VZ-CME : You must use 4 * M4 x L10 screws to assemble this monitor and the wall mount bracket.



WARNING !

If user uses screws longer than M4 x L10 mm, it may cause damage to the unit.
Please use bolt of correct size and length as instructed.



Mounting Safety !

At least two people are recommended to safely install the mount.

SPECIFICATION

250 cd/m²

Model No.	VZ-19CME	VZ-22CME	VZ-24CME	
Size & Type	19.5"	21.5"	24"	
LCD	Panel Type	19.5" LED Backlit Monitor	21.5" LED Backlit Monitor	24" LED Backlit Monitor
	Pixel Pitch	0.2767 (H) x 0.2767 (V) mm	0.2482 (H) x 0.2482 (V) mm	0.2767 (H) x 0.2767 (V) mm
	Brightness	250 cd/m ²	250 cd/m ²	300 cd/m ²
	Contrast Ratio	1000 : 1(Typ.)		
	Viewing Angle	R/L : 85°/ 85° U/D : 80°/ 80°		
	Display Color	16.7 Million Colors		
	Response Time	5 ms		
Max. Resolution	1600 (H) x 900 (V)	1920 (H) x 1080 (V)	1920 (H) x 1080 (V)	
Case Type	Black Plastic			
Active Display Area	432.0 (H)x 239.76 (V) mm	476.64 (H) x 268.11 (V) mm	521.28 (H) x 293.22 (V) mm	
Aspect Ratio	16 : 9			
Frequency	30-80KHz(H) / 50-75Hz(V)			
Color Temperature	5000K / 6500K / 7500K / 8200K / 9300K / 11500K / sRGB / USER			
Speaker	2 x 2.5W			
Operating Temperature	14°F ~ 122°F / -10°C ~ 50°C			
Operating Humidity	20 ~ 70% RH			
Weight	Net : 6.17 lb / 2.8 kg	Net : 7.71 lb / 3.5 kg	Net : 8.81 lb / 4.0 kg	
	Gross : 7.27 lb / 3.3 kg	Gross : 9.03 lb / 4.1 kg	Gross : 11.46 lb / 5.2 kg	
INTERFACE	HDMI (High Definition Multimedia Interface) DVI (Digital Video Interface), VGA (RGB-PC), PC Stereo In / Out			
Safety & EMC Certification	Energy Star / CE / FCC / ROHS / WEEE			
Electrical Ratings	12V DC, 3A (AC 100-240V, 50/60Hz)			
Power Consumption	≤ 19 W	≤ 23 W	≤ 28 W	
Accessories	HDMI cable, Power Supply & Cable, User's Manual, Remote controller (Battery is not included)			

TROUBLESHOOTING GUIDE

- Check the following before calling for service.
- If the same problems continue after checking, contact the reseller you purchased the monitor from.

At start	We recommend that you to test with different input sources when you have trouble with the current input source. If symptom persists, follow the instructions below. After following the instructions below, please contact us at 1-888-99-VIEWZ.
No image or Noise on the screen	<ul style="list-style-type: none"> - Make sure the cable is correctly plugged into the outlet - Make sure the power cable is correctly plugged into the monitor - Make sure the cable is correctly connected between monitor & source - Adjust brightness and check to see if brightness is set to 'Ø' - Check video source
Incorrect display or Half display	<ul style="list-style-type: none"> - Check your video source - Reset video source : connection, cable replacement, setting & more
Flickering and shadow image	<ul style="list-style-type: none"> - Check your input source setting regarding resolution and phase (Hz)
The audio function is not working	<ul style="list-style-type: none"> - Check the volume and make sure MUTE is not on - Check HDMI / Display port cable connection
LED is flickering or no image	<ul style="list-style-type: none"> - Check the interface cable connection and make sure it's plugged in correctly - Check the input source

TERMS OF WARRANTY / RMA

- The warranty period for this monitor is 3 years. The warranty will be voided for the scenarios listed below.
- You can also download the manual and information of VIEWZ web site: VIEWZUSA.COM

Cases of Non-Warranty Coverage	When power feed to the monitor exceeds capacity and causes damage
	Accident, Abuse, Misuse, Neglect, Fire, Water/liquids, Lightning or any act of nature
	Damaged by dropping, throwing and hitting the monitor
	Failure caused by users attempt to modify the product
	Failure by limited life of parts such as LED Lamps and any other consumables
	Damaged by using third party power cable, unstable power input and electric shock
	When shipping the monitor for RMA, make sure to pack safely to ensure the monitor is not damaged during shipping.

* Above information can be changed without notification - please check our website or contact ViewZ representative for latest RMA service policy.

WARRANTY

ViewZ USA LIMITED 3 YEAR WARRANTY

What and Who is Covered by this Limited Warranty and for How Long

ViewZ USA warrants this product to be free from defects in material and workmanship for 3 YEAR of the original owner of this product. The limited warranty is valid only for the original purchaser of the product.

What ViewZ USA Will Do

At the sole option of ViewZ USA, ViewZ USA will repair or replace any product or product part that is defective. If ViewZ USA chooses to replace a defective product or part, a replacement product or part will be shipped to you at no charge, but you must pay any labor costs.

What is Not Covered; Limitations

ViewZ USA DISCLAIMS ANY LIABILITY FOR DAMAGE TO MOUNTS, ADAPTERS, DISPLAYS, PROJECTORS, OTHER PROPERTY, OR PERSONAL INJURY RESULTING, IN WHOLE OR IN PART, FROM IMPROPER INSTALLATION, MODIFICATION, USE OR MISUSE OF ITS PRODUCTS.

ViewZ USA DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. ViewZ USA IS NOT RESPONSIBLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO, INABILITY TO USE ITS PRODUCTS OR LABOR COSTS FOR REMOVING AND REPLACING DEFECTIVE PRODUCTS OR PARTS. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

What Customers Must Do for Limited Warranty Service

If you discover a problem that you think may be covered by the warranty you MUST REPORT it in writing to the address below within thirty (30) days. Proof of purchase (an original sales receipt) from the original consumer purchaser must accompany all warranty claims. Warranty claims must also include a description of the problem, the purchaser's name, address, and telephone number. General inquiries can be addressed to ViewZ USA Customer Service at 1-888-998-4399. Warranty claims will not be accepted over the phone or by fax.

ViewZ USA
Attn: Warranty Claim
177 W. Orangethorpe Ave.
Placentia, CA 92870

How State Law Applies

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

Disclaimer

ViewZ USA intends to make this manual accurate and complete. However, ViewZ USA makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this monitor. The information contained in this document is subject to change without notice or obligation of any kind. ViewZ USA makes no representation of warranty, expressed or implied, regarding the information contained herein. ViewZ USA assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Contact Us

NORTH AMERICA
177 W. Orangethorpe Ave.
Placentia, CA 92870
USA and Canada
Phone: 1-888-998-4399
Fax: 1-714-996-1138
Other Locations
Phone: (001) 888-998-4399
Fax: (001) 714-996-1138