

BLIND SPOT SENSOR SYSTEM

RVS-118

REAR VIEW
SAFETY
REVERSE WITH CONFIDENCE™



DESCRIPTION

Our Blind Spot Sensor System mounts sensors on either side of the vehicle to alert you of vehicles in your side blind spots. One of the hardest to see areas around your vehicle while driving is the area slightly behind and to the side of the vehicle. This is precisely where these sensors mount to alert you of vehicles that would otherwise be hard to see. While there will always be visual alerts, audio warnings will only trigger if the turn signals are on. The visual alert for this system is strategically placed in the "A" pillar in the vehicle to be easily seen by the driver.

SPECIFICATIONS

Channel	2-Channel (Audio+Video)
Voltage	12V
Work Current	200mA
Static Current	40mA
Output	2.4W
Sensor Range	3.5m-6m
Detective Angle	100 degree



**DON'T MISS
WHAT'S IN YOUR
BLIND SPOTS!**

