

## FALL PREVENTION CUSHIONED SENSOR PADS

Emergency Caller Products new cushioned Sensor Pads are super soft and super thin, providing immediate notification of patients attempt to exit a wheelchair or bed.

Now... your patients can be completely comfortable and protected whether sitting or sleeping with **Sensor Pad** cushioned pads.

All pads come with an unconditional lifetime warranty.



#### Wheelchair/Seat Cushioned Sensor Pad

Model #SPC-6-22



Medium Sized Cushioned Bed Sensor Pad (14x24)

Model #SPC-3-22



Large Sized Cushioned Bed Sensor Pad (18x24)

Model #SPC-4-22

New Cushioned Sensor Pad works with all of these Emergency Caller Products.







**Other Manufacturer's Signaling Products** 

Emergency Caller Products



**Emergency Caller Products (T) 800-227-2474 (F) 800-762-7613** www.emergencycaller.com sales@emergencycaller.com

## P-22 Series Lifetime Sensor Pads

Lifetime Sensor Pads are available in many styles. Chair (seat), Bed and Floor. Exclusive Sensor **Strip** for Beds and Rails, allow total comfort and freedom of movement in bed. Pads are **super thin and patient** comfortable. Sensor Pads are slip resistant and Completely Waterproof! Complete with Soft touch sensor pad cover and mesh bag with an 8 ft. lead (except Chair-Seat Pad with 4 ft. lead).

Pads Quick Lock connect to Emergency Caller Universal Transmitters with RJ-22 plug. Lifetime Sensor Pads directly replace All disposal sensor pads. With Lifetime Guarantee, you never again need to be concerned about constant replacement and expensive costs! Cleans Quickly with Standard Disinfectant Products.

Sensor Pads detect both Applied Weight "Patient ON" pad or Removed Weight "Patient Off" Selection made by switch on Universal Transmitter Unit or other monitoring products.

**Model P-1-22 Strip Sensor Pad 1"** wide sensor strip mounts to bed mattress edge or on bed rails. Provides maximum comfort to patient. Signals when patient attempts to exit bed when legs or hips apply pressure to sensor strip at bed edge. Can be mounted 

Model P-2-22 Strip Sensor Pad 2" wide sensor strip. Mount on beds, chairs, floor and toilet. Mount on wall surfaces to provide "Press for Emergency" in bath-

Model P-3-22 Bed Sensor Pad mount against bed mattress directly under patient hip or back area. Lifetime Sensor Pads may be mounted underwater in shower, bath-

Model P-4-22 Bed Sensor Pad mount against bed mattress or on floor to detect patient exit attempts. Size: 18"x 24"

Model P-5-22 Bed/Hoor Sensor Pad larger area coverage mount against bed

Model P-6-22 Chair-Seat Sensor Pad signals patient attempts to exit. For wheelchair use (4 ft. cord), mounts under or on top of cushion. Can be used to detect patient in bathtub or shower for entry or exit (weight off or weight on). . . . Size: 9" x 16"

Model P-7-22 Chair-Seat Sensor Pad mount on longer and narrow seating areas such as spa edge, etc. Size: 6"x 24"

**Model P-8-22 Hoor Sensor Pad** placed on floor near bed or other areas to 

Model P-9-22 Hoor Sensor Pad large area sensor pads are placed on floor near bed or other areas to detect exit/entry or fallen patients. All sensor pads are slip 

Model P-10-22 Corrugated Hoor Sensor Pad industrial duty with corrugated material on top and bottom. Slip resistant to turning wheelchairs and gurneys. 

\*Sensor Pads are available with additional types of connectors, cable and lengths

Soft Touch cover included P-6-22, P-3-22, P4-22





















See Emergency Caller Product Index for all accessories for Products and Systems





## **XP Series**

# Built In Transmitter Lifetime Sensor Pads

**XP Series Lifetime Sensor Pads** are available with BUILT IN Universal Transmitters. Eliminating cords, wires and location requirements. XP Sensor Pad transmitter is contained in a waterproof pouch molded to SensorPad. Transmitter is easily accessible to turn ON when monitoring patient or Off while attending patient and to select mode of operation (Chair/Bed or Floor/Sensor Strip). XP Sensor Pads are available for ALL Emergency Caller 900MHz and Standard Range Products. For convenience and cost, you will be very pleased with XP Sensor Pads! With Lifetime Guarantee\*, you never again need to be concerned about constant replacement and expensive costs!

### **Supervised Wireless Built in Transmitter Sensor Pads** Operate with All Emergency Caller 900MHz receiver products

	_		•		
Model XP-1-900 S	Strip Sensor Pad		Sens	or Strip Size: 1"x 30	"
Model XP-2-900 S	Strip Sensor Pad		Sens	or Strip Size: 2"x 30	"
Model XP-3-900	Bed Sensor Pad		Senso	or Pad Size: 14"x 24	"
Model XP-4-900	Bed Sensor Pad		Senso	or Pad Size: 18"x 24	"
Model XP-5-900	Bed/Floor Sensor	Pad	Senso	or Pad Size: 24"x 30	"
Model XP-6-900	Chair-Seat Sensor	Pad	Sens	sor Pad Size: 9"x 16	"
Model XP-7-900	Chair-Seat Sensor	Pad	Sens	sor Pad Size: 6"x 24	"
Model XP-8-900 l	Floor Sensor Pad		Senso	or Pad Size: 24"x 36	"
Model XP-9-900 l	Floor Sensor Pad		Senso	or Pad Size: 24"x 60	"
Model XP-10-900	Corrugated Floor	Sensor Pad	Senso	or Pad Size: 24"x 36	"
Model XP-11-900	Corrugated Flooi	Sensor Pad	Senso	or Pad Size: 24"x 60	"
Model XP-12-900	) Toilet Sensor Stri	ip	Sei	nsor Pad Size: 1"x 3	"
Model XP-13-900	Incontinence Ser	nsor Pad	Sei	nsor Pad Size: 3"x 4	"





#### **Standard Range Built in Transmitter Sensor Pads** Operate with All Emergency Caller Extended Range receiver products

Model XP-1-300 Strip Sensor Pad Sensor Strip Size: 1"x 30"
Model XP-2-300 Strip Sensor Pad Sensor Strip Size: 2"x 30"
Model XP-3-300 Bed Sensor Pad Sensor Pad Size: 14"x 24"
Model XP-4-300 Bed Sensor Pad Sensor Pad Size: 18"x 24"
Model XP-5-300 Bed/Floor Sensor Pad Sensor Pad Size: 24"x 30"
Model XP-6-300 Chair-Seat Sensor Pad Sensor Pad Size: 9"x 16"
Model XP-7-300 Chair-Seat Sensor Pad Sensor Pad Size: 6"x 24"
Model XP-8-300 Floor Sensor Pad Sensor Pad Size: 24"x 36"
Model XP-9-300 Floor Sensor Pad Sensor Pad Size: 24"x 60"
Model XP-10-300 Corrugated Floor Sensor Pad Sensor Pad Size: 24"x 36"
Model XP-11-300 Corrugated Floor Sensor Pad Sensor Pad Size: 24"x 60"
Model XP-12-300 Toilet Sensor Strip Sensor Pad Size: 1"x 3"
Model XP-13-300 Incontinence Sensor Pad Sensor Pad Size: 3"x 4"





\*Lifetime Warranty limited to Sensor Pad only. Universal transmitters standard 1 year warranty



